

How To troubleshoot Canon Printer Error Code b200 issue?

Canon Printer Error Code b200



Florida, Apopka, Mar 7, 2021 ([Issuewire.com](https://www.issuewire.com)) - Canon Printer Error Code B200

The occurrence of a printer error is a common occurrence. However, failing to address the printer error promptly and correctly will result in hours of frustration and possibly printer failure. We Need a Different Approach & a Lot of Patience to Resolve Any Technical Error In Printer. Canon Error B200 is a Frequently Occurring Error, but the Good News is that it is Simple to Fix. If your cartridge carriage gets stuck and the green and orange lights blink 10 times in a row, that's the warning for [Canon Printer Error Code B200](#). For example, today we will cover the majority of topics related to the Canon B200 Error.

- What is Canon Printer Error B200 & Why it Occurred?
- Basic Steps to Troubleshoot Canon B200 Error.
- Advanced Troubleshooting to Fix Canon Error B200

It's time to get what is the Reason for Problem then need to Perform basic Troubleshooting –

Why Canon Printer Error B200 issue Arrived

Typically, this error is caused by a hardware anomaly in the Canon printhead or cartridge. To be more precise, let us list the causes of the B200 Error.

- Faulty Or Incorrectly Installed Canon Printhead
- InkClogged or Dirt in Printer Head
- Dried Out Or Problematic Ink Cartridges
- Corrupted Or Wrong version of Printer Driver

These types of issues lead to your [Canon Printer in Error State](#) so let's start with the basic steps.

Some Basic Steps

- Turn Off the canon Printer & Open the Print Cover Bey Examine the Printhead Alignment & Carefully Take it Out(To Take our canon Printhead Lift the lever Located Beside the Cartridge Cradle).
- Clean the Printhead and Remove Any Dirt Or ink clog
- Insert the Cartridges Back to Printhead & Lock the Printer Head Lever back to Printer Carriage.
- Keep the Printer Cover Open & Turn On the Printer. Once the Print Head starts Moving Towards the Left Please Shut the cover Before it reaches Till End of the Left Side of the Printer.
- Leave the Printer Power On and Let It Boot up all the settings. it's easy to download the driver & setup Canon Printer from the canon.com/ijsetup website.

How to Fix Canon Error Code B200?

Since there is no one-size-fits-all solution for Error B200, one solution should not be suitable for all Canon printers. Let's try a few more cool steps to see if they help—also, read [How to Fix Canon Error 5100](#) if you have a Canon printer.

Clean the Printhead

- Turn off the Canon Printer & Remove the Printer Cover.
- Lift the lever to Take out Printhead & remove the Cartridge From the Ink Holder.
- Carefully Use Alcohol, Water, Or Less Sticky Oil Content With a Cotton Or Microfiber Cloth to clean the Printhead Pins Properly. Do it Gently because Printhead is a Sensitive Device that can be damaged easily. After Cleaning let it air dry for 5 Minutes & Plug it back in.

Uninstall & Reconfigure the Printer

It's very doubtful. However, a Corrupted Or Incorrect Version of the Canon Printer Driver may also be to blame for the error, so uninstall the printer driver and download the most recent version of the software based on your printer model number.

- Replace Empty Or Dried Ink Cartridges & Always Buy Quality Ink Cartridge Direct From Canon.
- Replacing Tank Holders Or Printhead may also solve the Issues.
- Contact Canon Customer Support See if they have Got Any New Tricks Or They can Help You With Replacement.
- visit Canon Community and see other people sharing issues and Possible Causes of the issue.

sometimes Repair is not worth the Trouble & gamble if you can afford to Buy a New Canon Printer at a Cheap Price.

Hope this Guide Was Helpful or you can check out [how to reset the Canon printer b203 error to default settings](#).

Media Contact

Bruce hank

brucehank11@gmail.com

Source : Canon Printer Suppport

[See on IssueWire](#)